


DIAGRAM OF B21/45-A1



ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
101	2040100-02140-0	BOLT W/FLAT WASHER	212	2040400-04120-0	SPRING PIN	423	11323-1654701-1	POSITIONING SHEET
102	11369-110A401-1	CAP	301	11230-1106601-1	GUN BODY UNIT	424	11345-0014701-1	STOPPER
103	11370-0010003-1	SEAL	302	1132H-0964701-1	GASKET	425	2040101-02030-0	HEX.SOC.HD.BOLT
104	11360-0960001-1	COMPRESSION SPRING	303	1132T-0960002-1	MUFFLER	426	2040500-02010-0	LOCK NUT
105	11399-0960001-2	COLLAR	304	11346-096A402-1	END CAP	427	2040101-02040-2	HEX.SOC.HD.BOLT
106	2041100-03050-0	O - RING	305	11394-0964701-1	GUIDE PLATE	428	11338-1104701-1	SAFETY GUIDE
107	2041102-02050-0	O - RING	306	2040100-02070-0	BOLT ASSY	429	1130D-0254701-1	SPRING
108	11368-0960001-1	HD.VALVE PISTON	307	1132L-0014701-1	DUSTY COVER	430	11256-1104701-1	SAFETY B UNIT
109	2041104-03060-0	O - RING	308	1135V-0000003-1	AIR PLUG	431	1131C-0664701-1	RING
110	2041106-02050-0	O - RING	309	1133D-1104701-1	SPRING RETAINER	432	1137H-0264701-1	ADJUST AXIE
111	2041100-03040-0	O - RING	310	2040100-02090-2	BOLT ASSY	433	11254-1104701-1	SAFETY A UNIT
112	1132M-0964701-1	PACKING	401	2040101-02020-0	HEX.SOC.HD.BOLT	434	11324-1104701-1	FIXED PIN
113	2041106-02060-0	O - RING	402	11352-1654701-1	DRIVER GUIDE COVER A	435	11299-1104701-1	STOPPER UNIT
114	11204-1650001-1	DRIVER UNIT	403	11329-0964702-1	PIN	436	1131L-1100001-1	POSITIONING SPRING
115	11320-1650001-1	CYLINDER	404	2040101-02072-2	HEX.SOC.HD.BOLT			
116	2041105-03040-0	O - RING	405	11303-1654701-1	DRIVER GUIDE			
117	11321-1650001-1	CYLINDER SPACER	406	11339-1101101-1	PROTECTIVE CASING A			
118	2041105-04020-0	O - RING	407	2040101-01070-0	HEX.SOC.HD.BOLT			
119	11322-0034701-1	CYLINDER RING	408	2040101-01050-2	HEX.SOC.HD.BOLT			
120	11327-0734701-2	BUMPER	409	11389-1654701-1	MAGAZINE			
121	11388-1654701-1	DRIVER GUIDE	410	11377-1650001-1	FLAT BAR			
201	11373-0150001-3	TRIGGER VALVE HEAD	411	11389-1654702-1	MAGAZINE GUIDE			
202	2041102-01020-0	O - RING	412	2040400-03050-0	SPRING PIN			
203	1133U-0014701-1	SPRING	413	1133X-1104701-1	SPACER			
204	11375-0154701-1	PLUNGER	414	11363-1104701-1	PUSHER			
205	2041102-01030-0	O - RING	415	11367-1650001-1	PUSHER SPRING			
205A	2041102-01031-0	O - RING	416	11367-1650002-1	PUSHER SPRING			
206	2041109-02030-0	O - RING	417	11391-1654701-1	MAGAZINE B			
207	11374-0154701-1	PLUNGER CAP	418	1136H-1654701-1	FIXED SUPPORT			
208	11376-0154701-1	SPRING	419	11347-1654701-1	REAR PLATE			
209	11224-0154702-1	TRIGGER UNIT	420	2040400-04040-0	SPRING PIN			
210	2040400-04100-0	SPRING PIN	421	2040101-02030-2	HEX.SOC.HD.BOLT			
211	2040400-05120-0	SPRING PIN	422	1130T-1104701-1	STOPPER			